Remote Touch (If Equipped)

The Remote Touch can be used to operate the navigation screens and configure settings.

n Basic operation

1 Remote Touch knob
Use this knob to move the cursor and select items on the screen.
Feedback force, selection sounds and pointer shape can be changed. Refer to the "Navigation System Owner's Manual".

2 "ENTER" button
Push this button to confirm a selection.

3 "MAP/VOICE" button
Push this button to display the vehicle's current position.

4 "∧·∨" button
Push these buttons to change map scale and scroll through lists.

5 "MENU" button
Push this button to display the "Start" (menu) screen.

6 "DISP" button
Push this button to adjust picture quality.

n Start

Push the “MENU” button on the Remote Touch to display the “Start” screen.

1 Destination
2 Info.Phone
3 Setup
4 Climate (→P.40)
5 Audio (→P.36)

n Display





Push the “DISP” button on the Remote Touch to show the “Display” screen.

1 Turns the rear seat entertainment system on and off
2 Displays the screen in “Day Mode” with the headlight switch on
3 Turns the screen off
4 Adjust contrast
5 Adjust brightness
6 Adjust color tone
7 Adjust color

Navigation System (If Equipped)

n Register home



1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Setup.

3 Select Navi..

4 Select Home.

5 Select Set Home.

6 Select Address.

7 Select City.

8 Input a city name and select OK.

9 Select the button of the desired city name from the displayed list.

10 Input the street name and select OK.

11 When the desired street name is found, select the corresponding button.

12 Input a house number and select OK.

13 Select Enter.

14 Select OK.

n Destination input——Search by address





1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Destination.

3 Select Address.

4 Select City.

5 Input a city name and select OK.

6 Select the button of the desired city name from the displayed list.

7 Input the street name and select OK.

8 When the desired street name is found, select the corresponding button.

9 Input a house number and select OK.

10 Select Go to.

11 Select OK.

n Destination input——Search points of interest by name





1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Destination.

3 Select Point of Interest.

4 Select Name.

5 Input the name of the point of interest and select OK.

6 Select the button of the desired destination.

7 Select Go to.

8 Select OK.

n Destination input——— Search points of interest by category





1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Destination.

3 Select Point of Interest.

4 Select Category.

5 Select Near a Destination.

6 Select the button of the desired destination and set the search point.

7 Select the desired point of interest category.

8 Select the button of the desired item.

9 Select Go to.

10 Select OK.

n Destination input —— Search points of interest by telephone number



1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Destination.

3 Select Point of Interest.

4 Select Phone #.

5 Input a telephone number and select OK.

6 Select Go to.

7 Select OK.

Hands-free System For Cellular Phone (with navigation system)

n Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to "www.lexus.com/bluetooth" for more phone information.

To use a Bluetooth® phone, it is necessary to first register it in the system.

1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Setup.

3 Select Phone.

4 Select Manage Phone.

5 Select (add new) to display the screen for connecting Bluetooth.

6 Enter the passcode displayed on the screen into the phone.
Refer to the cellular phone user's manual for cellular phone operation.

7 When the connection is completed, a message will appear indicating that the phone has been connected successfully.

n Phonebook transfer



1. Push the MENU button.
   Please refer to P.24 for the Remote Touch operation.
2. Select Setup.
3. Select Phone.
4. Select Phonebook.
5. Select Manage Contacts.
6. Select Transfer Contacts.
7. Transfer the phonebook data to the system using the cellular phone.
   Refer to the cellular phone user's manual for cellular phone operation.

Phonebook transfer may not be possible depending on phone model.

n Registering a speed dial



1 Push the MENU button.
Please refer to P.24 for the Remote Touch operation.

2 Select Setup.

3 Select Phone.

4 Select Phonebook.

5 Select Manage Speed Dials.

6 Select New Speed Dial.

7 Select the data you want to register.

8 Select the desired phone number.

9 Select the button you want to register in.

10 The registration completion message is displayed on the screen.

n Calling by name

You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the "Navigation System Owner's Manual". Only when English is selected as the system language can you call by saying a name registered in the phonebook without registering any voice tags beforehand. (Names in the phonebook work as voice tags.)

STEP 1

STEP 2



STEP 4



1. Press .
2. Follow the voice guidance and say "Phone".
3. Follow the voice guidance and say "Dial by name".
4. Follow the voice guidance and say a contact name.
5. Follow the voice guidance and say the type of phone number (home, mobile, work, other).
6. Follow the voice guidance and say "Dial".

: Pressing this switch turns the speech command system on. Say a command after the beep.

n Receiving a call



1 When a call is received, this screen is displayed with a sound.

2 Push on the steering wheel to talk on the phone.

To ignore the call, push on the steering wheel.

n XM® NavWeather

The XM® NavWeather service that allows the navigation system to display weather information on the map is available if your satellite radio tuner can receive weather information. For details, refer to the "Navigation System Owner's Manual".

To receive the XM® NavWeather service, a subscription to the XM® Satellite Radio with NavWeather is necessary.

The XM® NavWeather is available in the contiguous 48 U.S. states. For details about the XM® NavWeather service coverage area, refer to www.xmradio.com.

l How to activate the XM® NavWeather service

To receive the XM® NavWeather service, it is necessary to activate the service. To activate the service, an extra fee is required in addition to subscription fees for the XM® Satellite Radio. For details about service an activation, call XM® Listener Care Center at 1-877-515-3987.

Customers should have their radio ID ready; the radio ID can be found by selecting "channel 000" on the radio.

XM® Satellite Radio has the responsibility for all fees and service, they are subject to change.

The following operations can be performed.

- **Show XM® NavWeather information**
- **Weather information**
- **Weather warnings**

Audio System (with navigation system)

n Audio control screen

Follow the procedure below to display the audio control screen.

1 Press the "MENU" button on the Remote Touch.
The "Start" screen will be displayed.

2 Using the Remote Touch, select "Audio" and press the "ENTER" button.

n Basic operation



1 Sound quality modes

2 Audio sources

AM·FM: AM radio/FM radio
SAT: Satellite radio*
DISC: DVD player (if equipped)
CD: CD player (if equipped)
AUX·USB: Auxiliary audio device/USB memory player/iPod® player

3 Power/Volume

n Radio



1 Station presets
2 Scanning radio stations
3 Radio tuner
4 Station select
5 Seek

n Entering station presets

1 Select the desired station by using the tune, seek or scan function.
2 Using the Remote Touch, select one of the preset switches (1-6), then press the "ENTER" button until a beep is heard, indicating that the station has been set.

n DVD player/CD player

n Playing an audio CD



1 Disc select
2 Repeat play
3 Random playback
4 Search playback
5 Disc load
6 Track select/rewind/fast-forward
7 Eject

n Playing a CD with MP3/WMA files



1 Disc select
2 Repeat play
3 Random playback
4 Search playback
5 Folder select
6 Disc load
7 File select
8 Eject

n Playing a DVD (DVD player only)



1 Disc select
2 DVD operation
3 Image display (full screen)
4 Disc load
5 Chapter select
6 Eject

n Loading a disc

1 Press the “LOAD” button.

2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

n Loading multiple discs

1 Press and hold the “LOAD” button until you hear a beep.

2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

3 After inserting a disc, wait until the indicator changes from flashing amber to green, then insert the next disc after the disc slot door has opened.

Repeat 2 and 3 until you have inserted all discs.

To cancel the operation, press the “LOAD” button. If you do not insert a disc within 15 seconds, loading will be canceled automatically.

n Remote control (steering wheel switches)

The audio system can be operated using the remote control located on the steering wheel.

1 Volume

2 Power on/change mode: press
Power off: press and hold

3 Radio mode: radio tuner
DVD mode: track/chapter/disc select
CD mode: disc/track/file (MP3/WMA) select

Air Conditioning System (with navigation system)

1 Dual mode button
2 Passenger side temperature display
3 Fan speed display
4 Outside air/recirculated air mode button
5 Passenger side temperature control
6 Air outlet selector button
7 Windshield defogger
8 Automatic mode button
9 Driver side temperature control
10 Fan speed control button/"OFF" button
11 Cooling and dehumidification function on/off button
12 Driver side temperature display
13 Air outlet display

n Using the automatic mode

Press 8 to turn on the airflow and 9 to adjust the temperature.

n Adjusting the temperature

n To simultaneously adjust the driver's side and passenger's side temperature settings

Select 1 to turn the "DUAL" indicator off (DUAL) and then press 9.

n To individually adjust the driver's side and passenger's side temperature settings

Select 1 or press 5 to turn the "DUAL" indicator on (DUAL) and then press 9 or 5.

n To turn off the airflow

Press and hold "∨" on 10 until the airflow turns off.

Hands-free System For Cellular Phone (without navigation system)

n Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to"www.lexus.com/bluetooth" for more phone information.

To use a Bluetooth® phone, it is necessary to first register it in the system.

1 Press or .

2 Press and say "Pair phone".

3 Press and say a name*.

*: This name will be used to identify your phone in the case that more than one phone has been registered to the system.

4 Press and say "Confirm" to display the passkey.

5 Enter the passkey shown on the display into the phone.
Refer to the cellular phone user's manual for cellular phone operation.

6 Once the voice guidance for registration completion is finished, press .

: Pressing this switch turns the speech command system on. Say a command after the beep.

n Calling by number

1 Press and say “Dial by number”.

2 Press and say the phone number.

3 Dialing

a. Press .

b. Press and say “Dial”.

n Calling by name

You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the “Owner's Manual”.

1 Press and say “Dial by name”.

2 Press and say a contact name.

3 Dialing

a. Press .

b. Press and say “Dial”.

: Pressing this switch turns the speech command system on. Say a command after the beep.

n Phonebook transfer

1 Press .

2 Press and say “Phone book”.

3 Press and say “Add entry”.

4 Press and say “By phone”.

5 Press and say “Confirm”.

6 Transfer the phonebook data to the system using the cellular phone.
Refer to the cellular phone user’s manual for cellular phone operation.

7 Press and say “Previous” or “Go back” until the desired data is displayed.

8 Press and say “Confirm”.

9 Press and say “Confirm” again.

Phonebook transfer may not be possible depending on phone model.

: Pressing this switch turns the speech command system on. Say a command after the beep.

n Registering a speed dial

1 Press .
2 Press and say “Phone book”.
3 Press and say “Set speed dial”.
4 Select the data to be registered.
5 Press and say the desired name.
6 Press and say “Confirm”.
7 Press the desired preset button.
8 Press and say “Confirm”.

: Pressing this switch turns the speech command system on. Say a command after the beep.

Audio System (without navigation system)

n Basic operation

▶ Type A

1 Power/Volume

2 Audio sources

AM·FM: AM radio/FM radio
SAT: Satellite radio
CD: CD player
AUX: Auxiliary audio device (if equipped)
AUX•USB: Auxiliary audio device/USB memory player (if equipped)/ iPod® player (if equipped)

3 Sound quality modes

▶ Type B

1 Power/Volume

2 Audio sources

AM: AM radio
FM: FM radio
CD: CD player
AUX: Auxiliary audio device

3 Mute

4 Sound quality modes

n Radio

▶ Type A

1 RDS genre select
2 Station presets
3 Radio tuner
4 Traffic information
5 Text messages
6 Scanning radio stations
7 Seek

n Entering station presets

1 Select the desired station by using the tune, the seek or the scan function.
2 Press and hold one of the preset buttons (1-6) until you hear a beep, indicating that the station is set.

▶ Type B

1 Station select
2 Station presets
3 Radio tuner
4 Scanning radio stations
5 Seek

n Entering station presets

1 Select the desired station by using the tune, the seek or the scan function.
2 Press and hold one of the preset buttons (1-6) until you hear a beep, indicating that the station is set.

n CD player

n Playing an audio CD

▶ Type A



1 Eject
2 Disc select
3 Random playback
4 Repeat play
5 Pause/Playback
6 Disc load
7 Text information
8 Search playback
9 Track select/rewind/fast-forward

▶ Type B



1 Eject
2 Disc select
3 Random playback
4 Repeat play
5 Disc load
6 Text information
7 Search playback
8 Track select/rewind/fast-forward

n Playing a CD with MP3/WMA files

▶ Type A



1 Eject
2 Disc select
3 Random playback
4 Repeat play
5 Pause/Playback
6 Folder select
7 Disc load
8 File select
9 Text information
10 Search playback

▶ Type B



1 Eject
2 Disc select
3 Random playback
4 Repeat play
5 Folder select
6 Disc load
7 File select
8 Text information
9 Search playback

n Loading a CD

1 Press the “LOAD” button.
“WAIT” is shown on the display.

2 Insert a CD when the indicators on the slot turn from amber to green.
The display changes from “WAIT” to “LOAD”.

n Loading multiple CDs

1 Press and hold the “LOAD” button until you hear a beep.
“WAIT” is shown on the display.

2 Insert a CD when the indicators on the slot turn from amber to green.
The display changes from “WAIT” to “LOAD”.
The indicators on the slot turn to amber when the CD is inserted.

3 Insert the next CD when the indicators on the slot turn from amber to green again.
Repeat the procedure for the remaining CDs.
To cancel the operation, press the “LOAD” button. If you do not insert a CD within 15 seconds, loading will cancelled automatically.

n Remote control (steering wheel switches)

The audio system can be operated using the remote control located on the steering wheel.

1 Volume

2 Power on/change mode: press
Power off: press and hold

3 Radio mode: radio tuner
CD mode: disc/track/file (MP3/WMA) select

Air Conditioning System (without navigation system)

1 Passenger side temperature display
2 Passenger side temperature control
3 Cooling and dehumidification function on/off button
4 Outside air/recirculated air mode button
5 Windshield defogger
6 Air outlet selector button
7 Driver side temperature control
8 Fan speed control button/"OFF" button
9 Automatic mode button
10 Dual mode button
11 Driver side temperature display

n Using the automatic mode

Press 9 to turn on the airflow and 7 to adjust the temperature.

n Adjusting the temperature

n To simultaneously adjust the driver's side and passenger's side temperature settings

Press 10 to turn the "DUAL" indicator off (DUAL) and then press 7.

n To individually adjust the driver's side and passenger's side temperature settings

Press 10 or 2 to turn the "DUAL" indicator on (DUAL) and then press 7 or 2.

n To turn off the airflow

Press and hold "∨" on 8 until the airflow turns off.

Speech Command System

n Basic operation

1 Press on the steering wheel.

2 - If you know the command:
Press again.
- If you do not know the command:
Follow the voice guidance to learn the command and then press again.

3 Say a command after the beep.

n Important speech commands information and tips

- Speech commands can be used while driving.
- You must wait until after the beep to say a command.
- In vehicles with a navigation system, a large TALK icon will appear on the navigation screen to prompt you to say a command.
- If you know what command to use, you can press at any time to interrupt the voice guidance.

n Command list

▶ **All vehicles**

<table>
<tr><th colspan="5">PHONE</th></tr>
<tr><td rowspan="8">To Operate a Bluetooth Connected Phone/Make Calls, SAY:</td><td rowspan="8">“Phone” and then SAY:</td><td colspan="2">“Dial by Name”</td><td rowspan="8">NOTE: You can also make a call by simply saying: “Call XXX-555-5555” ETC.</td></tr>
<tr><td colspan="2">“Dial by Number”</td></tr>
<tr><td colspan="2">“Redial”</td></tr>
<tr><td colspan="2">“Call Back”</td></tr>
<tr><td colspan="2">“Mute” or “Unmute”</td></tr>
<tr><td colspan="2">“Send Tones”</td></tr>
<tr><td rowspan="3">“Connect Phone” and then SAY:</td><td>“Select Phone”</td></tr>
<tr><td>“Add New Phone”</td></tr>
<tr><td>“Hands Free Power ON”</td></tr>
<tr><td colspan="2">“Hands Free Power OFF”</td></tr>
</table>

▶ **With navigation system**

<table>
<tr><th colspan="5">Destinations</th></tr>
<tr><td>To Enter an Address/ Destination, SAY: (English only)</td><td colspan="2">“Destination” and then SAY:</td><td colspan="2">“Address” and then follow the prompts to enter city, state, street and house number</td></tr>
<tr><td rowspan="5">To Enter a Point of Interest, SAY</td><td colspan="4">A Point of Interest Category, Such As: “Dining,” “Shopping Malls,” “Police,” “Gas,” ETC.</td></tr>
<tr><td rowspan="4">“Destination” and then SAY:</td><td rowspan="4">“Point of Interest” and then SAY:</td><td>“Near Here”</td><td rowspan="4">And then follow the prompts</td></tr>
<tr><td>“Along Route”</td></tr>
<tr><td>“Emergency”</td></tr>
<tr><td>“Phone Number”</td></tr>
<tr><td>To Enter a Previous Destination, SAY:</td><td colspan="2">“Destination” and then SAY:</td><td colspan="2">“Previous Destinations”</td></tr>
<tr><td rowspan="2">To Enter/Go to Preset Destinations, SAY:</td><td rowspan="2">“Destination” and then SAY:</td><td rowspan="2">“Presets” and then SAY:</td><td>“Home” (HOME must already be set using manual controls)</td></tr>
<tr><td colspan="2">“Preset 1” or “Preset 2” ETC. (preset addresses must already be set using manual controls)</td></tr>
</table>

General Navigation Commands	
To Change the Map Screen, SAY:	"Map"
	"Dual Map"
	"Single Map"
	"Compass Mode"
To Change the Map Scale/ Size, SAY:	"Zoom In"
	"Zoom Out"
	"Right Map Zoom In"
	"Right Map Zoom Out"
	"North Up"
	"Heading Up"
	"Map Direction"
To Change the Map Orientation, SAY:	"Right Map North Up"
	"Right Map Heading Up"
	"Right Map Direction"
To Change the Guidance Mode, SAY:	"Arrow Mode"
	"Turn List Mode"
	"Intersection Mode"
	"Freeway Mode"
To Save a Point on the Map, SAY:	"Mark This Point"
To Remove Icons from Map, SAY:	"Clear All Icons"
To Set the Destination, SAY:	"Previous Start Point"
To Change the Route, SAY:	"Quick Route"
	"Short Route"
	"Alternate Route"
	"Detour"
	"Detour Entire Route"

General Navigation Commands	
To Review the Route, SAY:	"Route Overview"
	"Next Destination Map"
	"First Destination Map"
	"Second Destination Map"
	"Third Destination Map"
	"Fourth Destination Map"
	"Fifth Destination Map"
	"Final Destination Map"
To Delete the Destination, SAY:	"Delete Next Destination"
	"Delete Final Destination"
	"Delete All Destinations"
To Operate Guidance Options, SAY:	"Pause Guidance"
	"Resume Guidance"
	"Repeat Guidance"
	"Louder"
	"Softer"
To Operate the Traffic Information, SAY:	"Traffic Information"
To Show the Icon, SAY:	"Show GAS", "Show PARKING" ETC.

AUDIO			
To Turn Audio On or Off, SAY:	"Audio ON"		
	"Audio OFF"		
To Change the Audio Mode, SAY:	FM, AM, Radio, Satellite Radio, Auxiliary, CD*, CD Changer*, DVD**, DVD Changer**, Bluetooth® Audio, iPod®, USB Audio		
	*For systems w/o NAV **For systems w/NAV		
To Change to a different CD/DVD track, SAY:	"Track Up", "Track Down" or "Previous Track"		
To Change to a different CD/DVD, SAY:	"Disc Up" "Disc Down"		
To Change Radio Stations, SAY:	"Seek Up" or "Seek Down"		
	"Type Up" or "Type Down"		
To Operate Satellite RadioXM Controls, SAY:	"Satellite Radio" and then SAY:	"Select Channel Number"	
		"Select Channel Name" (English only)	
		"Select Channel Type" (English only)	
		"Command List" and then SAY:	"Seek Up" or "Seek Down"
			"Type Up" or "Type Down"

XM Information		
To Operate XM NavWeather, SAY: (English only)	"Information" and then SAY:	"XM NavWeather" and follow the prompts
To Operate XM NavTraffic, SAY: (English only)	"Information" and then SAY:	"XM NavTraffic" and follow the prompts
To Operate XM Sports, SAY: (English only)	"Information" and then SAY:	"XM Sports" and follow the prompts
To Operate XM Stocks, SAY: (English only)	"Information" and then SAY:	"XM Stocks" and follow the prompts
To Operate Lexus Insider, SAY:	"Information" and then SAY:	"Lexus Insider" and follow the prompts

CLIMATE CONTROL/AIR CONDITIONING	
To Turn On and Adjust setting for Climate Control and Temperature, SAY:	"Automatic Climate Control"
	"Raise Temperature"
	"Lower Temperature"
To Set a Specific Temperature, SAY:	"70 Degrees" or "65 Degrees" ETC.

Portable Audio Device Adapters

These adapters can be used to connect a portable audio device and listen to it through the vehicle's speakers.

1 Slide the armrest while pulling up the lever, and lift the armrest.
Remove the upper tray.

2 Remove the lower tray and open the cover.



1 USB adapter (if equipped)
2 AUX adapter

Safety Connect (If Equipped)

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.
Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

n System components



1 Microphone
2 LED light indicators
3 "SOS" button

n Services

Subscribers have the following Safety Connect services available:

l Automatic Collision Notification*
In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

*: U.S. Patent No. 7,508,298 B2

l **Stolen Vehicle Location**
If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.
In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Lexus.com.

- **Emergency Assistance Button (SOS)**
  In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.
  If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.
- **Roadside Assistance**
  Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Lexus.com.

n Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.
A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987) or push the "SOS" button in your vehicle for further subscription details.

Lexus Enform with Safety Connect (If Equipped)

Lexus Enform and Safety Connect are subscription-based telematics services that use Global Positioning System (GPS) data, embedded cellular technology an XM® satellite data services to provide safety and security as well as convenience features to subscribers.

Lexus Enform and Safety Connect services are supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Lexus Enform service is available by subscription on select, telematics hardware-equipped vehicles.

For details, refer to the "Owner's Manual" and "Navigation System Owner's Manual".

n Services

▶ **With an active Lexus Enform subscription, the following features are available:**

l **Safety Connect features (→P.59)**

- Automatic collision notification*1
- Stolen vehicle location
- Emergency assistance button (SOS)
- Roadside assistance

l **Destination Assist**

Destination Assist provides you with live assistance for finding destinations via the Lexus Enform response center. You can request either a specific business, address, or ask for help locating your desired destination by category, such as restaurants, gas stations, shopping centers or other points of interest (POI).

After you tell the agent your choice of destination, its coordinates are sent wirelessly to your vehicle's navigation system.

l **eDestination**

With the eDestination feature, you can go online, via the Lexus.com owner's Web site, to select and organize destinations of your choice and then wirelessly send them to your vehicle's navigation system.

You can store up to 200 locations online to access and update at any time.

Your locations can be organized into up to 20 personalized folders.

You must first go online at www.lexus.com and go to the "Owners" section where you will need to register and log in. After this, you can create your personalized folders containing the locations you wish to send to your vehicle. (See Lexus Enform Guide for more information.)

l **XM® Sports and Stocks*2**

XM® Sports and Stocks is a service included with XM® satellite radio subscriptions for Lexus Enform vehicles. With this service, you can receive updates via the navigation system on your personally selected sports teams and stocks.

- **XM NavWeather™*3**
  The subscription-based XM NavWeather™ service allows the navigation system to display weather information on the map.
- **XM® NavTraffic*3**
  The subscription-based XM® NavTraffic service allows the navigation system to display traffic information on the map.

▶ **The following navigation-based Lexus Enform features are available without a subscription:**

- **Lexus Insider**
  Lexus Insider is an optional service that can send audio messages, or articles, to participating owner's vehicles via the navigation system. Potential Lexus Insider subjects might include, for example, Lexus vehicle technology tips, updates on regional Lexus events, or audio excerpts from Lexus Magazine articles. Up to 20 articles can be stored at a time.
- **Voice Command**
  The voice command system enables you to operate the navigation system, audio system and hands-free system by giving a command.

*1: U.S. Patent No. 7,508,298 B2

*2: Available at no extra charge with an active XM® satellite radio subscription.

*3: Available via separate XM® subscription(s).

n Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services. A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987), or push the "Destination Assist" button in your vehicle for further subscription details. XM NavTraffic® and XM NavWeather™ require separate XM® subscription(s). XM® Sports and Stocks is available with an XM® Satellite Radio subscription. After a 90-day free trial, you must set up the appropriate XM® subscription(s) to continue receiving these services.